

Instructions for Installation of Clear Acrylic Crash Cart Dividers (#1101-1105 and #3204-3205)

- 1.) Remove protective masking from dividers:
 - a.) Place divider on a flat surface.
 - b.) Starting at a corner of the divider, slowly lift and peel back the protective masking to remove. Repeat this process with each of the dividers.
- 2.) Place the short dividers widthwise into the crash cart tray with the “U”-shaped slots facing upwards.
- 3.) Insert the long dividers into the “U”-shaped slots of the short dividers. The “U”-shaped slots of the long dividers should face downwards, so that the slots “nest” together.

****CAUTION: Keep the dividers on a flat surface while removing the protective masking. Holding the dividers upright while pulling on the masking may cause the dividers to break.**

