

INSTRUCTIONS FOR Installation of Clear Acrylic Crash Cart Dividers (#1101-1105 and #3204)

1. Remove protective masking from dividers:
 - a. Place divider on a flat surface.
 - b. Starting at a corner of the divider, slowly lift and peel back the protective masking to remove.
Repeat this process with each of the dividers.
2. Place the short dividers widthwise into the crash cart tray with the "U"-shaped slots facing upwards.
3. Insert the long dividers into the "U"-shaped slots of the short dividers.
The "U"-shaped slots of the long dividers should face downwards, so that the slots "nest" together.

*****CAUTION: Keep the dividers on a flat surface while removing the protective masking. Holding the dividers upright while pulling on the masking may cause the dividers to break.***