
## Instructions for Kango Vinyl, Polyurethane, & Wood Seat Stools



1. When you receive your stool it should include the following: 1 five leg base, 1 center column, 1 seat, and 1 optional footrest on items #8426, 11690, and 11696.



2. A. If your stool has a footrest, slide the footrest onto the bottom of center column and position it at the desired level. The footrest position can be adjusted later when the user is sitting on the stool. B. Tighten the footrest with the adjustable knob (turn clockwise) when in the desired position.





3A. Insert the larger end of the center column into the 5-leg base.



3B. Push the center column into the base until it stops.



Kango® is a registered trademark of Biens Company.

REV.121902

## Instructions for Kango Vinyl, Polyurethane, & Wood Seat Stools



4. Slide the peg on the underside of the seat onto the top of the center column. Push the seat down until it latches onto the column.



lever to adjust seat height

5. The stool is now assembled and the height can be adjusted for the user or workstation by the seat height lever on the side of the seat.

