

INSTRUCTIONS FOR

Digital Clock/Timer (#10461)

Insert Battery Before Using

1. Slide battery cover on backside of timer case in direction of arrows.
2. Insert 1 AAA battery into opening, matching plus (+) and minus (-) symbols.
3. Slide cover down over battery, making sure it locks into place. Your timer is now ready to use.

To Set Clock

1. Press and hold CLOCK button for 5 seconds to enter clock mode.
2. Press HOUR and MINUTE buttons to set time.
3. Press CLOCK button to start the clock.

To Set Countdown Timers

1. Press one or all of the buttons labeled TIME 1, TIME 2, TIME 3 to enter the timer mode. All timers can operate at the same time.

T1 = TIME 1

T2 = TIME 2

T3 = TIME 3

2. Press HOUR, MINUTE or SECOND buttons to select desired time.
3. Press START/STOP/MEMORY button to start timing.
4. When time expires, a distinctive alarm will sound. The timer will continue to count up. The alarm will silence after 1 minute.
5. To stop timing, press START/STOP/MEMORY button. Press it again to restart.

Recall Previous Time

When countdown time has expired, press START/STOP/MEMORY once to pause timer twice to recall previous time, and again to start countdown timer.

Stopwatch Function

To start stopwatch, press START/STOP/MEMORY button once.

Stopwatch will immediately begin to count up at 1 second intervals.

To stop, press START/STOP/MEMORY button.

