

# INSTRUCTIONS FOR

## HCL® Rigid Sealing Tray for Micro Blisters (#21119)



**Step 1.** Place the blisters in the tray.



**Step 2.** Fill each blister cavity with a tablet or capsule.



**Step 3.** Peel the prepared labels from the 8½" x 11" sheet. Hold them by the edges and apply the label strip to the blisters in the sealing tray.



**Step 4.** Press the labels onto the blisters.



**Step 5.** Apply moderate pressure with a sealing roller to ensure a secure seal on the blisters.



**Step 6.** Remove the blisters from the sealing tray.